

VPI DIGGING SPECS CHEAT SHEET

	500 Top	540 IM	1000 TOP SEAM	1000 MID SEAM	1060 IM	1250 TOP SEAM	1250 MID SEAM	1500 TOP/ 1000 3CP	1500 MID SEAM	1530 IM	2000 TOP/ 1500 3CP	2500 TOP/ 2000 3CP
Tank Length	58"	64.9"	111"	102"	127"	135"	120"	132"	126"	175.6"	162"	201"
Tank Width	58"	61.7"	60"	58"	62.2"	60"	60"	68"	68"	61.7"	78"	78"
Tank Height	68"	54.6"	68"	68"	54.7"	68"	68"	68"	68"	54.5"	68"	68"
Inlet Invert	56"	47"	56"	56"	47"	56"	56"	56"	56"	47"	56"	56"
Outlet Invert	53"	44"	53"	53"	44"	53"	53"	53"	53"	44"	53"	53"
Dosing Outlet Invert	23"	13"	23"	23"	X	23"	23"	23"	23"	X	23"	23"
Pump Outlet Invert	54" OR 73"	45" OR 61"	54" OR 73"	54" OR 73"	X	54" OR 73"	54" OR 73"	54" OR 73"	54" OR 73"	X	54" OR 73"	54" OR 73"

****Invert measures bottom of pipe to bottom of tank****

****Hole should be dug AT LEAST two feet longer and wider to allow for level placement****

****Larger holes waste your time digging and limit our reach for proper tank placement****